# **Dial Indicators**

## SERIES 2 – Special Purpose Dial Indicators

### Adjustable-hand dial gauge

• The hand position can be adjusted independently of the position of the plunger by rotating the top knob.

## Peak-hold dial gauge

- A mechanism holds the pointer and the plunger at the position of maximum depression and hence displays the maximum value.\*
- \* Clearance of peak hold: push the nut in the direction of the arrow indicated in the dimensions diagram for 2046S-80.

0-50-0



### **Features**

Metric					
Code No.	50 0 10	10 0 10		STOP	<b>\</b>
20465-80	1	_	_	1	—
20485-10	1	_	1	_	1
Inch					
Code No.	50 0 10	10 0 10		STOP	
29155-10	1	_	1	_	1

1

#### **Optional Accessories**

29185-10

Contact points for Mitutoyo's dial indicators refer to pages F-37 to F-40 for details.

Interchangeable backs refer to page F-41 for details. Plunger lifting aids refer to page F-42 for details. Measuring stands refer to pages F-67 to F-72 for details.

## **Specifications**

Metric

Code No	Graduation	Range (range/rev)		Accuracy				Repeat-	Scale	Measuring
Code No.				Overall	Retrace	1/10 rev	1 rev	ability	Scale	force
20485-10	0.01 mm	mm 10 mm (1 mm		mm) 15 μm	3 µm	5 µm	10 µm	3 µm	0-100	1.4 N or less
2046S-80	0.01 1111									5.0 N or less
Inch								1		
Code No.	No. Graduation Range				Accuracy				Scale	Measuring
		(range/rev)	First rev / 2.5 rev / 10 rev Retra			Retrace	ability	Scale	force	
29155-10	.001"	.001" .5" (.1") ±		001"/±.001"/±.001"		.0002 "	±.0002"	0-100	1.8 N or less	
20100 10	1 .001	.) (.)	I	.001 /±	.001 /±	.001	.0002	1 I.0002		1.011 01 1855

#### Dimensions

2918S-10



